

RELIABLE SCALE CORPORATION

#6 – 1480 28 Street NE
Calgary, Alberta, Canada T2A 7W6
TELEPHONE: (403) 272-8784
TOLL FREE: (800) 419-1189
FAX: (403) 273-9818
E-mail: info@reliablescale.com

Web: www.reliablescale.com

Live Animal Weighing

December 7, 2012

Cattle-Logger™

RD Series IP Rated Connector Pinout

Power Connector (Top) - Pins on panel, Sockets on cable

Pin 1 − Power (12 to 24 VDC @ 3A)

Automatic Sorting
Pin 4 – Ground


Poultry Growth Monitors

Feed Mixer Scales

Pen & Platform Scales

Custom Load Cells & Pins

Load Cell Repairs



Power Connector (Cable end)

All Weather Weight

Indicators

Signal Connector (Bottom) - Sockets on panel, Pins on cable

Pin 2 − □ RS-232 Receive

Pin 3 − ■ RS-232 Transmit (optional)

Pump Jack Load Cells $Pin 4 - \blacksquare$ Ground


Mobile Weighing Systems

Wireline Load Sensors

R&D Projects

Data Loggers

Rentals



Signal Connector (Cable end)